


A.Features:

- ◆ 6 Digits LCD Display, Display Hour, Minute, Second, Week
- ◆ 12/24H format selectable, Auto Calendar.
- ◆ Daily Alarm and Chime hourly
- ◆ 1/100 second Chronograph with split functions.
- ◆ EL backlight

B.Operational Manual:

- ◆ Press B key to convert MODE:



At any mode, press A key or E key, the EL backlight on for 3 seconds.

C.Chronograph functions:

- ◆ In normal mode press B key once Chronograph, Press D to start, Press D again to stop, Press C to zero, Press B to normal mode

D.Alarm & Chime ON/OFF:

- ◆ In the normal mode, Press D and C key at the same time that enter into ON/OFF ALM  mode.
- ◆ In the normal mode, Press C and B key at the same time that enter into the ON/OFF SIG mode,  this symbol display means SIG on time,  when the symbol fade away means turn off SIG mode.
- ◆ In normal mode, press B key twice to enter Alarm mode, then press D key once, "Hour" flashing, press D key once again, "Minute" flashing, press C key, can adjust "Hour" and "Minute" respectively, press B key to normal mode.

E. Time & date setting:

- ◆ In the normal mode press C key will display Alarm; Press D key will display Date
- ◆ In normal mode, press B three times enter into setting mode and the "Seconds" flashing, press C key, "Minute", "Hour", "Date", "Month", "Week" Flashing successively. Press D key can adjust: Time, Minute, Month, Date, Week. Press B key to normal mode.

F.Adjust Hands Time:

1. Pull-out crown to stop the second hands stop.
2. Rotate crown to settle time.
3. After settle the time, push the crown firmly to the normal location.

**You can wear the watch when bathing and washing car.
But never push button in the water.**