

ACTIVE Pro



App Download

1

Use camera to scan the QR code to download

2

Search and download “WearPro” from Google PlayStore,

3

Bluetooth Connection

Search to connect: App->Device->Search(Mac address, on the watch main dial - pull down - "i") -> Click on "Smart Watch" to connect.


Scan to connect: App -> Device -> Scan
(QR code: On the watch face interface -> Pull down the menu -> Tap the QR code icon)



iOS



Playstore



Double-click

Menu interface: switch menu style

Short Press

Main dial: Enter menu

Menu interface: Back to main dial

Any interface: Back to previous page

Long Press

Any interface:Shutdown/Restart/ Factory reset

On any interface:

Short press: Screen off.

Long press: Wake up voice assistant.

Double-click: Enter sports mode.

Bluetooth Reconnection

- 1 When out of range, Bluetooth will disconnect. The app will automatically reconnect the Bluetooth within the range.
- 2 When closing the app or restarting the phone, Bluetooth will automatically disconnect. Open the App to reconnect.
- 3 To prevent the app from being closed by the phone system and causing Bluetooth disconnection, you can go to the App permissions settings and follow the prompts to enable the necessary permissions.
- 4 Audio Bluetooth: When the app connects to Bluetooth, an iPhone will automatically connect to the audio Bluetooth, while an Android phone will prompt you to choose 'Yes' to connect to the audio Bluetooth.

Main functions – Sports

Sports: Select sport – Choose a specific mode – Start, entering the sports interface. Pull down to display more data; Swipe right to pause the activity. At this point, you can choose from 3 options: exit the activity (without saving data), save (save activity data and exit), resume activity (continue the activity).

Exercise Records: All exercises initiated from the watch will be saved in this list.

Activity: Record daily steps, kilometers, and corresponding calorie count, as well as weekly step statistics.

Main functions – Health

Heart Rate: Upon entry, monitoring begins. Heart rate is measured by scanning the changes in capillaries on the skin's surface using green light. Swipe right to exit.

Heart rate refers to the number of times the heart beats per minute in a normal, resting state, also known as resting heart rate. It typically ranges from 60 to 100 beats per minute, but individual differences can occur due to age, gender, or other physiological factors.

Breathing: Deep breathing exercise.

Before training, you can set the duration of the breathing exercise (1 to 3 minutes) and the vibration speed (three levels).

During inhalation, the vibration will switch to exhalation; during exhalation, the vibration will switch to inhalation.

After training, the screen displays the training results, including heart rate, duration of training, and other data.

Blood Oxygen: It refers to the oxygen in the blood, and the normal blood oxygen saturation level in the human body is above 95%.

Sleep: Wearing the watch while sleeping, it will automatically record (nighttime) sleep, helping users better understand their sleep patterns, adjust their daily routines, and improve sleep quality.

Reminder:

Sedentary Reminder: The device monitors the user's activity levels. If there is prolonged inactivity, it will vibrate and illuminate the screen, reminding the user to stand up and move around to ensure adequate rest and physical health.

Hydration Reminder: Within the app, users can set reminder times. When the specified time arrives, the watch will vibrate and light up the screen, reminding the user to drink water.

Basic Functions

Firmware Upgrade: Bluetooth is connected normally. Check for updates in the App – Device – Firmware Version.

During the upgrade, keep the watch close to the phone and stationary, and wait for the upgrade to complete.

If disconnection occurs during the upgrade process, please wait for the phone to automatically reconnect to continue the upgrade. Remember not to restart the watch.

Switch Watch Face:

On the main watch face interface, long press for 3 seconds to enter the watch face switching interface. You can scroll right or left to cycle through available watch faces.

Default Watch Face: The first watch face, cannot be deleted.

Add More Watch Faces: Swipe right on the default watch face, or swipe left to the bottom to enter the "Watch Face Market". Choose your preferred category and watch face, then quickly install it into the outer watch face list.

Customize Watch Faces: To the left of "Add More Watch Faces" is where custom watch faces are located. You need to design them from the App –

Device - Watch Face Market - Custom Watch Faces section. You can upload your own images for watch face design.

Delete Watch Faces: If there is a red delete button below the watch face, you can delete it. After deletion, if you want to restore it, you can download it again from the Watch Face Market or App. Custom watch faces and default watch faces cannot be deleted.

Contacts: After connecting Bluetooth, open the App - Device - Frequently Contacted section, select the contacts you want to sync, and sync them to the watch. Please be patient and wait for the synchronization to complete.

Recents:

- Apple iPhone: Go to Phone Settings - Bluetooth - Smart Watch - Tap the "i" icon - Sync Contacts - Enable.
- Android Phone: Navigate to Phone Settings - Bluetooth - Tap on Smart Watch - System Popup - Check "Allow access to contacts and call logs" - Pair.

Message Notifications: Sync notifications received on the mobile phone, such as QQ, WeChat, Facebook, etc. The messages received on the watch are consistent with those on the mobile phone.

Swipe up on the main watch face to enter the message notification list, then swipe down to exit.

App Notifications: Go to the App settings on your device, select "App Notifications," and enable notifications for the corresponding application.

SMS Alerts: In the App settings on your device, choose "SMS Notifications," and turn them on.

Incoming Call Alerts: Navigate to the App settings on your device, select

"Incoming Call Alerts," and enable them (Note: Only alerts and rejection are available. You can answer calls after connecting to Bluetooth audio).

Weather: After connecting to the app, the current weather for the current location can be automatically synced. Due to the asynchronous nature of data syncing, there may be a delay of 2-4 hours.

Music:

- Phone Mode: This mode allows you to play and control music from your phone, including functions like play, pause, previous track, next track, and volume adjustment. (Upon first use of this feature, there may be a delay. If there's no response upon clicking, open the music app on your phone.)
- Local Mode: Switching to this mode automatically disconnects Bluetooth audio. You can play music saved locally on the watch. (Friendly reminder: This mode affects answering incoming calls. You need to switch back to Phone Mode.)
- Headphone Mode: Search for and connect Bluetooth headphones. Once connected, you can use the headphones for listening to music and answering calls.

Alarm clock, Stopwatch, Timer:

- Alarm clock: You can set the time for the alarm to ring and the repeat cycle (for example, repeat every Monday to Friday). The watch can store up to 5 alarms. Alarms set on the app and the watch will synchronize with each other. This means that alarms set on the app will sync to the watch, and vice versa.
- Stopwatch: Measures time intervals accurately.
- Timer: Precisely counts down time. You can quickly select 1, 2, 5, 10, 15, 20, or 30 minutes for the countdown, or you can customize the time.

Recorder:

- When Bluetooth audio is connected: Starting a recording will automatically disconnect Bluetooth audio; exiting the recording function will automatically reconnect Bluetooth audio.

- While playing music from your phone: Playback will automatically pause.
- During playback of recordings: Recordings are arranged with the latest recorded audio at the top. You can delete recording entries.

Camera:

- After opening the app and connecting via Bluetooth, you can utilize this feature.
- The watch allows for remote control of the phone's camera, with photos automatically saved to the phone's gallery (not the watch's).
- If the watch enters the camera function, the app will automatically switch to this function; similarly, if the app enters the camera function, the watch will also switch to this function automatically.

Gallery, Video:

Gallery:

- Click on any photo to view it in full screen.
- Swipe up: View the previous photo.
- Swipe down: View the next photo.
- Long press: Access the menu for setting the photo as wallpaper.

Video:

- Click to play the video.
- Pause and volume adjustment functions are currently not supported.
- Swipe right to exit video playback.

Calculator: Perform simple addition, subtraction, multiplication, and division operations.

AI Voice:

The voice assistant of the connected phone.

- This feature cannot be used when audio Bluetooth is not connected. Please switch back to "phone mode".
- Tap the screen to wake up the voice assistant, then you can engage in voice conversations with it, such as voice search or voice chat.

Find Phone: When connecting via Bluetooth, to locate the phone, it will ring or vibrate (depending on the user's phone settings):

- Apple phones: Open the App, see the reminder popup, click to cancel, and the ringing or vibration will stop.
- Android phones: Open the App, and the ringing or vibration will cease.

Game: Provides 7 games including 2048, Snake, Flappy Bird, Color Weakness Test, Tower of Hanoi, Digital Huarong Dao, and Box Pushing.

Flashlight: The watch will display a white light, providing illumination for the user.

Other Functions

Language, Time, Date: Once the watch is connected to the mobile APP, it will synchronize the phone's language, time, and date.

Common Settings: Pull down on the main watch face to display frequently used settings.

Mode Switch: Headphone icon. Switch between three modes, with effects similar to the mode switch description in the [Music] function.

Animation Effects: 3D icon. Set different page-turning effects, akin to transition effects in PPT.

Device Information: "i" icon. Includes the watch's name, MAC address, version information, etc.

Volume Settings: Sound icon. Adjust the system's volume level.

Vibration Settings: Watch vibration icon. 0 for no vibration, 1-3 for low, medium, and high vibration intensity, respectively.

Screen-off Timer Settings: The far right icon on the second row. Set the screen-off timer for 5-60 seconds, or choose to keep the screen always on.

Connect Bluetooth and Download App: QR code icon. Scan the QR code with a browser to enter the guided download page; scan the QR code with the watch's

App to connect and bind the watch normally.

Brightness Settings: Sun icon. Set the brightness level from 0-4.

Power Saving Mode: Battery icon. Tap the icon and then "Confirm" to enter power-saving mode, or tap back to not enter this mode.

Upon entering Power Saving Mode:

- The brightness and vibration levels are automatically adjusted to the lowest settings.
 - The screen-off timer is automatically set to 15 seconds.
 - Wrist flip screen-on feature is automatically turned off.
 - Audio Bluetooth is automatically disabled.
- To exit Power Saving Mode: Tap the battery icon again.
- In Do Not Disturb Mode (indicated by a moon icon):
 - Message notifications, call alerts, and SMS reminders are all automatically disabled.
 - Sedentary reminders and hydration alerts will not vibrate or light up the screen.
 - Alarms will continue to ring or vibrate as scheduled.
 - For wrist flip settings (indicated by a hand icon):
 - When enabled, the screen will automatically turn on with a wrist flip; when disabled, it will not.
 - For other settings (indicated by a toolbox icon):
 - Additional detailed settings can be found in this feature.

FCC Statement

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy

and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FAQ

How to Set Up Message Notifications?

- Open the APP, go to Devices - Message Alerts, select the corresponding software, and choose to turn it on.
- For other operations, refer to [Main Features - Basic Category - Message Notifications.

What to do if you're not receiving notifications?

- The watch's message alert function merely mirrors notifications from the phone. If notifications are received on the phone, the same messages will be received on the watch; likewise, if the phone does not receive them, the watch won't either.
- Therefore, the first step is to go to your phone's settings under Notifications, find the corresponding APP, and turn on the notification permission. For Apple phones: Go to Settings → Bluetooth → Find Smart Watch → Tap the "i" icon → Turn on "Share System Notifications."
- For Android phones: Open the App → Go to Devices → App Notifications → Blue text "Notification Access" → Tap WearPro → Turn off Notification Access → Turn it on again.
- If the problem persists, uninstall the App and download and install the latest version. During the installation process, agree to all permissions when prompted.

The watch cannot answer calls?

Open the mobile app and connect Bluetooth and audio Bluetooth. If the audio Bluetooth is not connected, you can only hang up and cannot answer the call.

Apple phone: Audio Bluetooth can be connected with one click; Android phone: After connecting Bluetooth, the system will ask whether to connect the audio, please select "Yes".

If the watch shows that Bluetooth is connected but the audio is not connected, it may be because your watch is currently in "local mode" and you cannot answer calls in this mode. Pull down the main dial interface, click the headset icon, switch to mobile phone mode, and you can resume answering calls.



warn:

Please consult your doctor before starting a new exercise program. Although smart watches can monitor real-time dynamic heart rate, they cannot be used for any medical purposes.